

Thank you for purchasing the MFJ-107B 24 Hour LCD clock

OPERATION PROCEDURE

SET TIME: Press the SET button and the display will flash. Press the HOUR button to set the desired hour. Press the MINUTE button to set the desired minute. The seconds will reset to "00" each time minute set is advanced. After setting press SET button once to end.

REPLACING THE BATTERY: When the display is fading or losing contrast, the battery should be replaced. To replace the battery, simply rotate the battery door out in the direction indicated. Take out the old battery, put new battery in with positive sign viewing upward. Replace the battery door. Use 1.5V button cell, G12 or 386 battery.

